# TS-201 Turbo Station

# User Manual (Version: 2.0.0)

©Copyright 2007. QNAP Systems, Inc. All Rights Reserved.

## FOREWORD

Thank you for choosing QNAP products! This user manual provides detailed instructions of using TS-201. Please read carefully and start to enjoy the powerful functions of TS-201!

## NOTE

- All features, functionality and other product specifications are subject to change without prior notice or obligation.
- All brands and products names referred to are trademarks of their respective holders.

## LIMITED WARRANTY

In no event shall the liability of QNAP Systems, Inc. (QNAP) exceed the price paid for the product from direct, indirect, special, incidental, or consequential software, or its documentation. QNAP makes no warranty or representation, expressed, implied, or statutory, with respect to its products or the contents or use of this documentation and all accompanying software, and specifically disclaims its quality, performance, merchantability, or fitness for any particular purpose. QNAP reserves the right to revise or update its products, software, or documentation without obligation to notify any individual or entity.

**CAUTION**

1. Back up your system periodically to avoid any potential data loss. QNAP disclaims any responsibility of all sorts of data loss or recovery.
2. Should you return any components of TS-201 Turbo Station package for refund or maintenance, make sure they are carefully packed for shipping. Any form of damages due to improper packaging will not be compensated.

# Table of Contents

**Table of Contents** ..... **3**

**Safety Warnings** ..... **6**

**Chapter 1. Overview of TS-201 Turbo Station** ..... **7**

1.1 Introduction ..... 7

1.2 Package Contents ..... 8

1.3 Hardware Illustration ..... 9

**Chapter 2. Install TS-201** ..... **10**

2.1 Install Hard Disk ..... 10

2.2 Hard Disk Recommendation List ..... 12

2.3 Set up TS-201 ..... 14

2.4 Check System Status ..... 16

2.5 Configure Software Settings ..... 18

*2.5.1 Windows® Users ..... 18*

*2.5.1.1 Using Mozilla Firefox ..... 35*

*2.5.2 Mac Users ..... 37*

**Chapter 3. Enjoy the Powerful Services of TS-201** ..... **43**

3.1 Server Administration ..... 48

3.2 Quick Configuration ..... 49

3.3 System Settings ..... 53

*3.3.1 Server Name ..... 53*

*3.3.2 Date & Time ..... 54*

*3.3.3 Encoding Setting ..... 55*

*3.3.4 View System Settings ..... 55*

3.4 Network Settings ..... 56

*3.4.1 TCP/ IP Configuration ..... 56*

*3.4.2 Microsoft Networking ..... 59*

*3.4.3 Apple Network ..... 61*

*3.4.4 Web File Manager ..... 61*

*3.4.5 FTP Service ..... 62*

*3.4.6 Multimedia Station ..... 64*

*3.4.7 Download Station ..... 65*
*3.4.8 Web Server ..... 66*
*3.4.9 DDNS Service ..... 67*
*3.4.10 View Network Settings ..... 69*

3.5 Device Configuration ..... 70

*3.5.1 SATA Disk ..... 71*
*3.5.2 USB Disk ..... 73*
*3.5.3 USB Printer ..... 74*

3.6 User Management ..... 76

*3.6.1 Users ..... 76*
*3.6.2 User Groups ..... 78*
*3.6.3 Quota ..... 85*

3.7 Network Share Management ..... 87

*3.7.1 Create ..... 88*
*3.7.2 Property ..... 89*
*3.7.3 Access Control ..... 90*
*3.7.4 Delete ..... 90*
*3.7.5 Restore ..... 91*

3.8 System Tools ..... 92

*3.8.1 Alert Notification ..... 93*
*3.8.2 Restart/ Shutdown ..... 93*
*3.8.3 Hardware Settings ..... 94*
*3.8.4 System Update ..... 95*
*3.8.5 Change Logo ..... 96*
*3.8.6 Remote Replication (Disaster Recovery) ..... 97*
*3.8.7 Backup/ Restore/ Reset Settings ..... 100*
*3.8.8 Network Recycle Bin ..... 101*

3.9 Event Logs ..... 102

**Chapter 4. Copy Data Directly by Front USB Port to TS-201 ..... 103**

**Chapter 5. Multimedia Station ..... 104**

5.1 Share Photos and Multimedia Files via Web Interface ..... 104
5.2 Enable iTunes Service ..... 111
5.3 Use UPnP Media Server ..... 113

**Chapter 6. Download Station ..... 116**

**Chapter 7. Web Server ..... 126**

**Chapter 8. FTP Server ..... 130**

**Chapter 9. Web File Manager ..... 133**

**Chapter 10. NetBak Replicator ..... 139**

**Chapter 11. TS-201 Maintenance ..... 154**

11.1 Restart/ Shut down Server ..... 154

11.2 Reset Administrator Password and Network Settings ..... 155

11.3 Disk Failure or Malfunction ..... 156

11.4 Power Outage or Abnormal Shutdown ..... 156

**Technical Support ..... 157**

**GNU GENERAL PUBLIC LICENSE ..... 158**

# Safety Warnings

1. TS-201 can operate normally in the temperature of 0°C-35°C and relative humidity of 0%-85%. Please make sure the environment is well-ventilated.
2. The power cord and devices connected to TS-201 must provide correct supply voltage (60W, 90-264V).
3. Do not place TS-201 in direct sunlight or near chemicals. Make sure the temperature and humidity of the environment are in optimized level.
4. Unplug the power cord and all connected cables before cleaning. Wipe TS-201 with a wet towel. Do not use chemical or aerosol to clean TS-201.
5. Do not place any objects on TS-201 for the server's normal operation and to avoid overheat.
6. Use the flat head screws in the product package to lock the hard disks in TS-201 when installing hard disks for proper operation.
7. Do not place TS-201 near any liquid.
8. Do not place TS-201 on any uneven surface to avoid falling off and damage.
9. Make sure the voltage is correct in your location when using TS-201. If you are not sure, please contact the distributor or the local power supply company.
10. Do not place any object on the power cord.
11. Do not attempt to repair your TS-201 in any occasions. Improper disassembly of the product may expose you to electric shock or other risks. For any enquiries, please contact the distributor.

# Chapter 1. Overview of TS-201 Turbo Station

## 1.1 Introduction

Thank you for choosing TS-201 Turbo Station. This product has the following key features:

- ✓ 9-in-1 server: Multimedia Station, Download Station, Mirror Station, Disaster Recovery, Web Server, Backup Server, File Server, FTP Server, and Printer Server.
- ✓ Easy-to-use, simple configuration in a few steps and TS-201 is ready to use!
- ✓ Supports RAID 0, RAID 1 and JBOD disk volume
- ✓ Web interface for authority configuration and folder management, even novice can mange the server easily
- ✓ Supports PHP and SQLite to establish interactive websites
- ✓ Embedded digital album supports automatic thumbnail generation, easy backup, browsing and sharing of photos
- ✓ Supports UPnP (DLNA compatible) multimedia technology for sharing of multimedia files at home
- ✓ Supports iTunes service to enable computers in LAN to play the songs shared by TS-201 via iTunes
- ✓ Supports 2 large-sized SATA disks and hotswap function
- ✓ 3 high speed USB 2.0 ports to support multiple USB devices like printer, disk, digital camera, thumb drive, card reader etc. to provide diversified functions.
- ✓ High speed transfer, 480Mbps USB 2.0, Gigabit Ethernet, 1.5GB SATA high speed file transfer. With highly efficient block level algorithm, data transfer can be done instantly.
- ✓ Block level remote replication for secure data backup
- ✓ Incomparable high reliability: NetBak Replicator for instant and schedule backup
- ✓ Independent BT, HTTP and FTP to minimize electricity expense
- ✓ Supports Network Recycle Bin, files deleted by mistake can be restored

## 1.2 Package Contents

Your TS-201 package contains:

- ✓ TS-201 Turbo Station

- ✓ Adaptor

- ✓ Power cord

- ✓ CD-ROM (user manual, Quick Install Wizard & utility inclusive)

- ✓ Quick Installation Guide

- ✓ Flat head screws x 8

- ✓ Ethernet cable x 1

- ✓ Front panel x 1

- ✓ Thumb screws x 4

## 1.3 Hardware Illustration




*__Note:__ TS-201 has a built-in Smart Fan. When the system temperature reaches 48ºC, the fan will operate immediately. Therefore, it is normal that the Smart Fan does not rotate when the system starts up.

# Chapter 2. Install TS-201

## 2.1 Install Hard Disk

1. Loosen the screws on the disk trays and take out the disk trays.

2. Install a hard disk on each tray. Make sure the disk holes match the holes at the base of the disk tray and lock the disk with four screws.

3. Insert the disk trays to TS-201. Push the disk trays to the end. Fasten the screws on the trays. When two disks are installed, make sure HDD1 is installed on top of HDD2.

4. Remove the protection films on the LED panel and both sides of the front panel.

5. Cover TS-201 with the front panel and fasten the four screws.

## 2.2 Hard Disk Recommendation List

The following HDD models are verified by QNAP that are compatible with TS-201. It is recommended to use the disk models listed here. Other HDD brands that are not tested by QNAP may or may not work properly with TS-201. For more updated compatible hard disk information, please visit QNAP website at http://www.qnap.com.

**QNAP disclaims any responsibility for product damage/ malfunction or data loss/ recovery due to misuse or improper installation of hard disks in any occasions for any reasons.**

| Seagate | | | | | |
|---|---|---|---|---|---|
| **Model Name** | **Model No.** | **Interface** | **Capacity (GB)** | **Rotational Speed (RPM)** | **Buffer Size (MB)** |
| Barracuda 7200.10 SATA | ST3750640AS | SATA II 3Gb/s with NCQ | 750 | 7200 | 16 |
| Barracuda 7200.9 SATA | ST3500641AS | SATA II 3Gb/s with NCQ | 500 | 7200 | 16 |
| Barracuda 7200.9 SATA | ST3400633AS | SATA II 3Gb/s with NCQ | 400 | 7200 | 16 |
| Barracuda 7200.8 SATA | ST3400832AS | SATA 1.5Gb/s with NCQ | 400 | 7200 | 8 |
| Barracuda 7200.10 SATA | ST3320620AS | SATA II 3Gb/s with NCQ | 320 | 7200 | 16 |
| Barracuda 7200.9 SATA | ST3300622AS | SATA II 3Gb/s with NCQ | 300 | 7200 | 16 |
| Barracuda 7200.9 SATA | ST3250824AS | SATA II 3Gb/s with NCQ | 250 | 7200 | 8 |
| Barracuda 7200.8 SATA | ST3250823AS | SATA 1.5Gb/s with NCQ | 250 | 7200 | 8 |
| Barracuda 7200.7 SATA | ST3160827AS | SATA 1.5Gb/s with NCQ | 160 | 7200 | 8 |
| Barracuda 7200.7 SATA | ST3120827AS | SATA 1.5Gb/s with NCQ | 120 | 7200 | 8 |

| Maxtor | | | | | |
|---|---|---|---|---|---|
| **Model Name** | **Model No.** | **Interface** | **Capacity (GB)** | **Rotational Speed (RPM)** | **Buffer Size (MB)** |
| Grizzly | 3H500F0 | SATA II 3Gb/s | 500 | 7200 | 16 |
| Grizzly | 3H400F0 | SATA II 3Gb/s | 400 | 7200 | 16 |
| DiamondMax 10 | 6L300S0 | SATA 1.5Gb/s with NCQ | 300 | 7200 | 16 |
| DiamondMax 10 | 6L250S0 | SATA 1.5Gb/s with NCQ | 250 | 7200 | 16 |
| DiamondMax 10 | 6L200M0 | SATA 1.5Gb/s with NCQ | 200 | 7200 | 8 |
| DiamondMax 10 | 6B200M0 | SATA 1.5Gb/s with NCQ | 200 | 7200 | 8 |

| Hitachi | | | | | |
|---|---|---|---|---|---|
| **Model Name** | **Model No.** | **Interface** | **Capacity (GB)** | **Rotational Speed (RPM)** | **Buffer Size (MB)** |
| Deskstar 7K500 | HDS725050KLA360 | SATA II 3Gb/s with NCQ | 500 | 7200 | 16 |
| Deskstar 7K400 | HDS724040KLSA80 | SATA 1.5Gb/s | 400 | 7200 | 8 |

| Western Digital | | | | | |
|---|---|---|---|---|---|
| **Model Name** | **Model No.** | **Interface** | **Capacity (GB)** | **Rotational Speed (RPM)** | **Buffer Size (MB)** |
| WD Caviar SE16 | WD5000KS | SATA II 3Gb/s | 500 | 7200 | 16 |
| WD Caviar SE16 | WD4000KS | SATA II 3Gb/s | 400 | 7200 | 16 |
| WD Caviar® SE Serial ATA | WD4000KD | SATA 1.5Gb/s | 400 | 7200 | 16 |
| WD Caviar® RE2 | WD4000YR | SATA 1.5Gb/s | 400 | 7200 | 16 |
| WD Caviar SE16 | WD2500KS | SATA II 3Gb/s | 250 | 7200 | 16 |
| WD Caviar® SE Serial ATA | WD2500KD | SATA 1.5Gb/s | 250 | 7200 | 16 |
| WD Caviar SE | WD2000JS | SATA II 3Gb/s | 200 | 7200 | 8 |
| WD Caviar SE | WD1600JS | SATA II 3Gb/s | 160 | 7200 | 8 |
| WD Caviar® SE Serial ATA | WD1600JD | SATA 1.5Gb/s | 160 | 7200 | 8 |

## 2.3 Set up TS-201

Please check your network environment and select the appropriate installation method before installing TS-201.

**1. Office / Home**

Connect TS-201 and PC to the same hub/ switch/ router.




**2. Individual**

Connect TS-201 directly to your PC by a network cable.



When you have verified your network environment, please follow the steps below to install TS-201.




1. Connect TS-201 to the hub/ switch/ router or PC according your network environment.
2. Connect USB printer to TS-201 and enable USB printer service*.
3. Connect the power.
4. Turn on TS-201.

* ***Note:*** *Please connect a USB printer to the server after the software configuration is completed.*

## 2.4 Check System Status

TS-201 provides LED indicators for you to indicate the system status and information easily. When TS-201 is turned on, please check the following items to make sure the system status is normal. Note that the following LED information is applicable only when you have properly installed HDD1 and/or HDD2, and connected TS-201 to the network and power.

❶ Power
❷ LAN
❸ HDD2
❹ HDD1
❺ Status
❻ USB Status

| LED | System starting up | System has started |
|---|---|---|
| ❶Power | Blue | Blue |
| ❷Network (LAN) | Blink in orange | Orange |
| ❹/❸HDD1/ HDD2 | Orange →Blink in orange | Off |
| ❺Status | Blink in red (short beep once) → Blink in green (long beep once) | Green |

**LED Display & System Status Overview**

| LED | LED Display & System Status |
|---|---|
| ❶Power | Blue: System has started |
| ❷LAN | Blink in orange: Accessing network |
| ❹/❸HDD1/ HDD2 | Blink in orange: Accessing data |
| ❺Status | Green: System is normal |
| | Blink in green: Hard disk not detected |
| | Blink in red: Bad blocks are found in hard disk |
| | Blink in green for 5 seconds, blink in green and red alternatively: Hard disk not initialized |
| | Blink in green and red alternatively: Disk capacity is almost full (long beep twice) |
| | Blink in red: Disk full |
| ❻Front USB Status | Blue: You can press the copy button to copy data.<br>Blink in blue: Copying data<br>Blink in blue once: Detecting or removing USB device |

| Other Status | | | |
|---|---|---|---|
| **Action** | **LED** | **In Process** | **Finished** |
| Update firmware | ❶Power | Blink in blue | Blue |
| | ❺Status | Blink in green and red alternatively | Green (long beep thrice) |
| System shut down | ❶Power | Blink in blue | Off |
| | ❺Status | Off (short beep once) | Off |
| HDD standby mode | ❶Power | Blue | N/A |
| | ❺Status | Off | |
| RAID 1 degraded mode | ❶Power | Blue | N/A |
| | ❺Status | Red (long beep twice) | |
| RAID 1 rebuilding | ❶Power | Blue | Blue |
| | ❺Status | Blink in red (long beep twice) | Green |

## 2.5 Configure Software Settings

After checking the system status, please follow the steps below to configure the software settings of TS-201. The configuration procedure of Windows and Mac users are different. Please select the appropriate procedure according to your OS.

### 2.5.1 Windows® Users

Insert TS-201 CD-ROM in your PC. Wait for a few seconds until the following screen shows up. Then start to configure the software settings of TS-201.

1. Select **TS-201**.



2. Install Quick Install Wizard.



3. Run Quick Install Wizard. When the wizard prompts for performing quick configuration, click **OK**.

4. Enter the default user name and password.

| |
|---|
| Default user name: **administrator**<br>Password: **admin** |



When you have entered quick configuration page, follow the instructions to complete the settings.  Click **Next** to continue.


Quick Configuration Wizard - Welcome
Welcome to the quick configuration wizard. This wizard will guide you through the following steps to configure this system quickly:
1. Enter the server name.
2. Change the administrator password.
3. Enter the date, time and time zone for this server.
4. Select the filename encoding setting for non-Unicode O.S. or FTP applications.
5. Enter the IP address, subnet mask and default gateway for this server.
6. Initialize the disk volume on this server.
Tips
Changes to all settings will be effective only when you confirm in the last step.
< Back
Next >
Cancel

Step 1. Enter the server name and click **Next**.


Quick Configuration Wizard - Step 1
Enter the name for this server.
Server Name :
NAS556677
Tips
You must assign a unique name for your server for the ease of identification within the local network.
The length of server name can be up to 14 characters, which can be a combination of alphabetical letters (A-Z or a-z), numbers (0-9) and hyphens (-). The server will not accept spaces, period (.), or other symbols.
< Back
Next >
Cancel

Step 2. Enter a new password or select to use the original password. Click **Next** to continue.


Quick Configuration Wizard - Step 2
Change the administrator password.
Password :
*****
Verify Password :
*****
Use the original password
Tips
If you select "Use the original password", the administrator password will not be changed.
Password is case-sensitive and must not exceed 16 characters. Due to security issues, the password should be at least 6 characters. Try to avoid using codes that are easily deciphered.
< Back
Next >
Cancel

Step 3. Select the time zone of your location or enter the date and time manually.  You can also select to synchronize the time of TS-201 with an Internet time server automatically.  Click **Next** to continue.


Quick Configuration Wizard - Step 3
Enter the date, time and time zone for this server.
Time Zone:
(GMT+08:00) Taipei
Change the server's time and date as below:
Date:
21/08/2006
Time:
16:11:21
Synchronize with an Internet time server automatically
Server:
pool.ntp.org
Tips
You can enable Internet time server to keep the system time updated when this server is connected to the Internet.
< Back
Next >
Cancel

Step 4. Select the encoding language of TS-201 and click **Next**.


Quick Configuration Wizard - Step 4
Select the filename encoding setting for non-unicode O.S. or FTP applications.
Filename Encoding:
English
Tips
The default filename encoding this server uses is Unicode, which works well with Unicode supported O.S. such as Windows 2000/XP and MAC OS X.
If you are using non-Unicode supported O.S., like Windows 95/98/ME, please select the same language of your O.S. for filename encoding.
Since Unicode is not supported by most FTP software, please select language that your FTP client supports for proper display of file names on the server.
< Back
Next >
Cancel

**Note:** All files and directories on TS-201 will be created using Unicode encoding. If your FTP client or PC does not support Unicode, e.g. Windows® 95, 98, ME OS, select the language the same as the OS of your PC here in order to view the files and directories on the server properly.

Step 5. It is recommended to use DHCP protocol to acquire IP address automatically. If your network does not support DHCP, please enter the IP address settings and click **Next**.


Quick Configuration Wizard - Step 5
Enter the IP address, subnet mask and default gateway for this server.
Obtain TCP/IP settings automatically via DHCP
Use the following static IP settings:
IP Address:
169 . 254 . 100 . 100
Subnet Mask:
255 . 255 . 0 . 0
Default Gateway:
169 . 254 . 100 . 100
Primary DNS Server:
0 . 0 . 0 . 0
Secondary DNS Server:
0 . 0 . 0 . 0
Tips
Please enter correct DNS Server settings if you use static IP settings. Or the NTP and alert mail function may not work properly.
< Back
Next >
Cancel

**Note:** If you select to enter IP address manually, please make sure your PC and TS-201 are in the same LAN. If you are not sure about the network settings, please contact your network administrator or ISP.

Step 6. When one or two hard drives are installed in TS-201, select the RAID configuration and click **Next** to format.


Quick Configuration Wizard - Step 6
Initialize the disk volume on this server.
Physical Disks Information
Dis...
Disk Model
Disk Capacity
Drive 1 ATA Maxtor 7Y250M0 YAR5 233.76 GB
Drive 2 ATA ST3160827AS 3.42 149.05 GB
Choose RAID Configuration
Same configuration as the current one
Single
Raid 1
Raid 0
JBOD
Tip
Except you choose "Same configuration as the current one" all data on the disk will be deleted.
< Back
Next >
Cancel

**Warning:** All data on the drives will be deleted unless you select "Same configuration as the current one".

Step 7. You have finished quick configuration.  Please make sure all settings are correct and click **Next** to start disk formatting.



Step 8. Please wait patiently when formatting the disk(s). Formatting may take a few minutes depending on the capacity of your hard drives. When finished, click **Next** to proceed.


Quick Configuration Wizard
Please wait while quick configuration wizard is doing changes for you. This may take a few minutes.
✔ Change the name for this server.
✔ Change the administrator password.
✔ Change the time settings.
✔ Change the filename encoding
✔ Change the network settings.
✔ Initialize the hard disk.
✔ Restart the server.
Configuration process complete.
< Back
Next >
Cancel

Congratulations!  You have finished Quick Configuration.  Your TS-201 is ready to use.

TS-201 provides several default share folders for data sharing and access.  To map the share folders on TS-201 as your drive, check the option **"Continue to map network drive for me"** and follow the steps below to proceed.  To start to use TS-201 immediately, you can skip to 5.


Quick Configuration Wizard - Finish
Congratulations. You have finished all the Configuration steps.  Your server is ready to use now.
Continue to map network drive for me.
< Back
Finish
Cancel

a. For example, to map the folder **Public** as your drive, select the folder and click **Map Network Drive**.




**Note:** The share folders Qdownload, Qmultimedia, Qusb, and Qweb are system default network share of TS-201 for the use of Download Station, Multimedia Station, USB auto-copy and Web Server.

b. Enter the default user name and password.



c. Select the drive letter for the connection and click **Finish**.


Map Network Drive
Windows can help you connect to a shared network folder and assign a drive letter to the connection so that you can access the folder using My Computer.
Specify the drive letter for the connection and the folder that you want to connect to:
Drive:
X:
Folder:
\\NAS556677\Public
Browse...
Example: \\server\share
Reconnect at logon
Connect using a different user name.
Sign up for online storage or connect to a network server.
< Back
Finish
Cancel

d. Upon successful connection, you can start to use the share folder on TS-201. You can access these folders by opening My Computer.



5. Quick Install Wizard will appear when all configurations are completed. Click on the name of TS-201 on the list to enter administration page.



6. When the administration page of TS-201 is shown, you can start to use the services. If you have any questions during web administration, please click the help button on the top right hand corner of the page.
   To modify system settings, click **Administration**. Enter the user name and password to login.

| |
|---|
| Default user name: **administrator**<br>Password: **admin** |


TS-201 Turbo Station
Administration
Change Password
SSL login
English
Web File Manager
Web Server
Multimedia Station
Download Station
A reliable and high capacity network attached storage server
• Share your storage over Microsoft and Apple network.
• Easy administration through simple web interface.
Welcome to TS-201
Thank you for using TS-201. TS-201 provides diversified applications and functions for you to enjoy pioneer technology.
(C) Copyright QNAP Systems, Inc. All rights reserved. Version 2.0.0 build 1207T

**Note:**
1. It is recommended to use Internet Explorer 6.0 or above to access TS-201. If the OS of your PC is Windows® 98, TS-201 supports Internet Explorer 6.0 or above only.
2. TS-201 also supports Mozilla Firefox.

#### *2.5.1.1 Using Mozilla Firefox*

For higher security, some Firefox versions will close the ports of certain services. The default port for TS-201 administration is 6000. To use port 6000 to access TS-201 via Firefox, you need to open this port in Firefox via the following steps.

(1) Enter **about:config** in the browser.

(2) A list of settings will be shown. Right click the page and select **New** and click **String**.




(3) Enter **network.security.ports.banned.override** in the dialog and click **OK**.



(4) Then enter **6000** and click **OK**.




(5) The setting will be added to the list. You can now use Firefox to access port 6000 of TS-201.



### 2.5.2 Mac Users

A. Connect TS-201 by Mac directly or B. Connect TS-201 by the network.

**A. Connect TS-201 by Mac directly**

1. Please go to **Network** settings and select **Using DHCP**. Then connect TS-201 to your Mac via a cable.




2. Open a web browser and enter the default IP address of TS-201 to login the system.

| Default IP of TS-201: **http://169.254.100.100:6000** |
|---|

**Note:** It is recommended to access TS-201 by Mozilla Firefox in Mac. Safari does not support Download Station of TS-201. Please refer to Chapter 2.5.1.1 for the information of using Mozilla Firefox.

3. When the administration page is shown, click **Administration**. Enter the default user name and password to login.

| |
|---|
| Default user name: **administrator**<br>Password: **admin** |


TS-201 Turbo Station
Administration
Change Password
SSL login
English
Web File Manager
Web Server
Multimedia Station
Download Station
A reliable and high capacity network attached storage server
• Share your storage over Microsoft and Apple network.
• Easy administration through simple web interface.
Welcome to TS-201
Thank you for using TS-201. TS-201 provides diversified applications and functions for you to enjoy pioneer technology.
(C) Copyright QNAP Systems, Inc. All rights reserved. Version 2.0.0 build 0105

4. Follow the step-by-step guide in Quick Configuration to complete the settings of TS-201. If you have any questions during web administration, please click the help button on the top right hand corner of the page.


NAS8A57E4
QNAP
Quick Configuration
Welcome
Step 1
Step 2
Step 3
Step 4
Step 5
Step 6
Finish
Welcome
Welcome to the quick configuration wizard. This wizard will guide you through the following steps to configure this system quickly:
1. Enter the server name.
2. Change the administrator password.
3. Enter the date, time and time zone for this server.
4. Select the filename encoding setting for non-Unicode O.S. or FTP applications.
5. Enter the IP address, subnet mask and default gateway for this server.
6. Initialize the disk volume on this server.
Note: Changes to all settings will be effective only when you confirm in the last step.
Continue

**B. Connect TS-201 by the network**

1. Please go to **Network** settings to check and write down the subnet and router address of your Mac. Then select **Using DHCP**.




**Note:** If you are not sure about the network settings, please contact your network administrator or ISP.

2. Connect TS-201 to your Mac by a cable. Open a web browser and enter the default IP address of TS-201.

Default IP address of TS-201: **http://169.254.100.100:6000**

**Note:** It is recommended to access TS-201 by Mozilla Firefox in Mac. Safari does not support Download Station of TS-201. Please refer to Chapter 2.5.1.1 for the information of using Mozilla Firefox.

3. When the administration page is shown, click **Administration**. Enter the default user name and password to login.

| |
|---|
| Default user name: **administrator**<br>Password: **admin** |


TS-201 Turbo Station
Administration
Change Password
SSL login
English
Web File Manager
Web Server
Multimedia Station
Download Station
A reliable and high capacity network attached storage server
• Share your storage over Microsoft and Apple network.
• Easy administration through simple web interface.
Welcome to TS-201
Thank you for using TS-201. TS-201 provides diversified applications and functions for you to enjoy pioneer technology.
(C) Copyright QNAP Systems, Inc. All rights reserved. Version 2.0.0 build 0105

4. Go to TCP/IP Configuration of Network Settings . Select to use static IP and input the IP address of TS-201. Make sure the value does not conflict with the IP address of your Mac and other devices in LAN. Configure the subnet mask and default gateway of TS-201 to the same as subnet mask and router address of Mac which you set in Step 1. Click **Apply** to confirm.


Network Settings
TCP/IP Configuration
Microsoft Networking
Apple Networking
Web File Manager
FTP Service
Multimedia Station
Download Station
Web Server
DDNS Service
View Network Settings
TCP/IP Configuration
Obtain IP address settings automatically via DHCP
Use static IP address
Fixed IP Address 192 . 168 . 0 . 3
Subnet Mask 255 . 255 . 255 . 0
Default Gateway 192 . 168 . 0 . 1
Primary DNS Server 0 . 0 . 0 . 0
Secondary DNS Server 0 . 0 . 0 . 0
Enable DHCP Server
Start IP Address 192 . 168 . 0 . 100
End IP Address 192 . 168 . 0 . 200
Lease Time 1 Day(s) 0 Hour(s)
Current connection status
Connection speed: 1000 Mbps, MTU: 1500 Bytes
Jumbo Frame Setting (MTU)
- Jumbo frame will only work in Gigabit network environment. Please make sure your clients are configured to use the same frame size.
- Jumbo frame setting will work only when all network appliances connected have enabled jumbo frame and use the same MTU value.
Select Jumbo Frame setting: Disable Jumbo Frame, MTU value is 1500 bytes
Apply

**Note:** When using static IP, please make sure your Mac and TS-201 are in the same subnet. If you are not sure about the settings, please contact your network administrator or ISP.

5. Please wait patiently for TS-201 to restart.

6. Connect your Mac and TS-201 to the network. Open a web browser and enter the IP address of TS-201 you set up in step 4.

# Chapter 3. Enjoy the Powerful Services of TS-201

TS-201 provides the following powerful functions and applications.

**A. Use network share-Public folder**

1. You can access the public folder of TS-201 by the following means:
   a. Open My Network Places and find the workgroup of TS-201. If you cannot find the server, please browse the whole network to search for TS-201. Double click the name of TS-201 for connection.
   b. Use Run function in Windows®. Enter **\\[TS-201 name]*** or **\\[TS-201 IP]#** to access share folder on TS-201.







   c. Windows® users can use Quick Install Wizard to find TS-201. When the administration page is shown, click **Web File Manager**. Enter the user name and password, and then start to manage TS-201.

2. You can upload files to the Public folder.

## B. Manage TS-201

- **Manage TS-201 using web browser by Windows® or Mac**

1. You can access TS-201 web administration page by the following methods:
   a. Use Quick Install Wizard to find TS-201.
   b. Open a web browser and enter **http://[TS-201 IP]:6000**#

**Note:**
1. It is recommended to use Microsoft® Internet Explorer 6.0 or above to access TS-201. If the OS of your PC is Windows® 98, TS-201 supports Internet Explorer 6.0 only.
2. Please use Mozilla Firefox to access TS-201 in Mac.

*The user name here should be the same as the server name you enter in Chapter 2.5 **Configure Software Settings**.

#The IP address here should be the same as the IP address you enter in Chapter 2.5 **Configure Software Settings**. If you are using DHCP: (a) connect the PC to TS-201 directly, please use the default IP address 169.254.100.100:6000 of TS-201; (b) connect TS-201 by network, please run Quick Install Wizard to view the IP address of TS-201.

2. When the administration page is shown, click **Administration**, **Web File Manager**, **Web Server**, **Multimedia Station**, or **Download Station**. Enter the user name and password, and then start to manage TS-201.

3. TS-201 supports SSL secure login which enables you to configure and manage the server by encrypted transfer. To use this function, check the box **SSL login** on the administration page and login the server.

> **Note:** If your TS-201 is placed behind an NAT gateway and you want to access TS-201 by secure login from the Internet, you must open the port 443 on your NAT and forward this port to TS-201 LAN IP.


TS-201 Turbo Station
Administration
Change Password
SSL login
English
Web File Manager
Web Server
Multimedia Station
Download Station
A reliable and high capacity network attached storage server
• Share your storage over Microsoft and Apple network.
• Easy administration through simple web interface.
Welcome to TS-201
Thank you for using TS-201. TS-201 provides diversified applications and functions for you to enjoy pioneer technology.
(C) Copyright QNAP Systems, Inc. All rights reserved. Version 2.0.0 build 1207T

## C. Use TS-201 Services

- **Multimedia Station**

  TS-201 provides a user-friendly web management interface for you to manage and share personal albums and multimedia files via network easily. Supports embedded iTunes Server music sharing, UPnP and DLNA standard multimedia technology to establish home multimedia sharing center. Please refer to Chapter 5.

- **Download Station**

  TS-201 supports BT, FTP, and HTTP download. You can add download tasks to TS-201 and let the server finish downloading independently of your PC. Please refer to Chapter 6.

- **Mirror Station**

  Provides RAID 1 mirroring disk volume for data protection. Please refer to Chapter 3.5.1.

- **Disaster Recovery**

  TS-201 supports remote share folder backup via the network. In case of data damage in PC, you can restore all backup data. Please refer to Chapter 3.8.6.

- **Web Server**

  TS-201 enables you to create your own website easily. It also supports PHP and SQLite to establish interactive websites. Please refer to Chapter 7.

- **Printer Server**

  TS-201 supports network printer sharing function by direct USB connection. No extra help from PC is needed. Please refer to Chapter 3.5.3.

- **FTP Server**

  TS-201 offers the simplest FTP server setup procedure for you to establish FTP server without any professional assistance. Please refer to Chapter 8.

- **Backup Server**

  NetBak Replicator is a powerful backup software designed for Windows users to configure automatic backup schedule. Block level remote replication is supported to provide the most reliable, instant and secure data backup mechanism. Please refer to Chapter 10.

- **File Server**

  TS-201 provides convenient and secure file server functions that support central data management. Users can be granted with the right to access network share and share important files. Please refer to Chapter 3.7 and Chapter 9.

## 3.1 Server Administration

There are 8 main sections in server administration:



## 3.2 Quick Configuration

Please follow the step-by-step guide in Quick Configuration to complete the settings of TS-201. If you have any questions during web administration, please click the help button on the top right hand corner of the page. Other buttons are described as below:

: Return to previous page

: Return to home page

: Logout system


>NAS567
QNAP
Quick Configuration
Welcome
Step 1
Step 2
Step 3
Step 4
Step 5
Step 6
Finish
– Welcome
Welcome to the quick configuration wizard. This wizard will guide you through the following steps to configure this system quickly:
1. Enter the server name.
2. Change the administrator password.
3. Enter the date, time and time zone for this server.
4. Select the filename encoding setting for non-Unicode O.S. or FTP applications.
5. Enter the IP address, subnet mask and default gateway for this server.
6. Initialize the disk volume on this server.
Note: Changes to all settings will be effective only when you confirm in the last step.
Continue

Step 1. Enter the server name.



Step 2. Change the administrator password or select to use the original password.


2. Change the administrator password.
Password :
Verify Password :
Use the original password
Note: If you select "Use the original password", the administrator password will not be changed.
Back
Next

Step 3. Enter the date, time and select the time zone for the server.


3. Enter the date, time and time zone for this server.
Time Zone :
(GMT+08:00) Taipei
Current date and time :
2006 / 7 / 24 AM 10 : 48 : 43
Change the server's time and date as below:
Date: January , (mm dd, yyyy)
Time: : : AM (hh:mm:ss)
Synchronize with an Internet time server automatically
Server: pool.ntp.org Test (Status: --)
Back
Next

Step 4. Select the language the server uses to display files and directories. The default setting is **English**.

Step 5. Enter the IP address, subnet mask and default gateway for the server.


5. Enter the IP address, subnet mask and default gateway for this server.
Obtain TCP/IP settings automatically via DHCP
Use the following settings
IP Address:
169 . 254 . 100 . 100
Subnet Mask:
255 . 255 . 0 . 0
Default Gateway:
0 . 0 . 0 . 0
Primary DNS Server
0 . 0 . 0 . 0
Secondary DNS Server
0 . 0 . 0 . 0
Note: If you don't need a default gateway for this server, please enter "0.0.0.0".
Back
Next

**Note:**

1. Please contact your ISP or network administrator for the IP address of primary and secondary DNS servers. When TS-201 plays the role as a terminal and needs to perform independent connection, e.g. BT download, you must enter at least one DNS server IP for proper URL connection. Otherwise, the function may not work properly.
2. If you select to obtain IP address via DHCP, there is no need to configure the primary and secondary DNS servers. You can enter "0.0.0.0" in the settings.

Step 6. Initialize disk volume in TS-201 for the first time configuration.




Step 7. When TS-201 is initialized, the basic settings will be shown.


Your system setting is as below, please click "Finish" to initialize the system.
Server Name : NAS567
Time Zone : (GMT+08:00) Taipei
Time Setting: 2006 / 07 / 24 AM 10 : 49 : 48
Filename Encoding: English
Network : DHCP
Disk : Do not initialize
Back
Finish

## 3.3 System Settings

Basic system settings include the server name, date, time, and view system settings.




### 3.3.1 Server Name

Enter the name of TS-201. The server name can be 14 characters long at maximum, which supports alphabets, numbers and hyphen (-). The server does not accept names with space, period (.), or names in pure number.



### 3.3.2 Date & Time

Set the date, time, and time zone according to your location. If the settings are incorrect, the following problems may occur:

- ✓ When using a web browser to access or save a file, the display time of the action will be incorrect.
- ✓ The time of event log displayed will be inconsistent with the actual time when an action occurs.




- ✓ **Synchronize with an Internet time server automatically**

  You can enable this option to update the date and time of the system automatically with specified NTP (Network Time Protocol) server. Enter the IP address or domain name of the NTP server, e.g. time.nist.gov, time.windows.com. Then enter the time interval for adjusting the time.




**Note:** The first time you enable NTP server, it may take several minutes for time synchronization before the time is correctly adjusted.

### 3.3.3 Encoding Setting

Select the language TS-201 uses to display files and directories.

**Note:** All files and directories on TS-201 will be created using Unicode encoding. If your FTP clients or the OS of your PC does not support Unicode, e.g. Windows® 95/98/ME, select the language the same as your OS here in order to view the files and directories on the server properly.

### 3.3.4 View System Settings

You can view all current system settings, e.g. server name, on this page.



## 3.4 Network Settings

You can configure network settings in this section and enable several powerful applications of TS-201, e.g. Multimedia Station, Download Station, and Web Server.

### 3.4.1 TCP / IP Configuration

You can select one of the following two methods to configure the TCP/IP settings of TS-201.


Network Settings
TCP/IP Configuration
Microsoft Networking
Apple Networking
Web File Manager
FTP Service
Multimedia Station
Download Station
Web Server
DDNS Service
View Network Settings
TCP/IP Configuration
Obtain IP address settings automatically via DHCP
Use static IP address
Fixed IP Address
Subnet Mask
Default Gateway
Primary DNS Server
Secondary DNS Server
Enable DHCP Server
Start IP Address
End IP Address
Lease Time
Day(s)
Hour(s)
Current connection status
Connection speed: 100 Mbps, MTU: 1500 Bytes
Jumbo Frame Setting (MTU)
- Jumbo frame will only work in Gigabit network environment. Please make sure your clients are configured to use the same frame size.
- Jumbo frame setting will work only when all network appliances connected have enabled jumbo frame and use the same MTU value.
Select Jumbo Frame setting:
Disable Jumbo Frame, MTU value is 1500 bytes
Apply

1. **Obtain IP address settings automatically via DHCP**
   If your network supports DHCP, TS-201 will use DHCP protocol to retrieve the IP address and related information automatically.
2. **Use static IP address**
   To use fixed IP address for network connection, enter fixed IP address, subnet mask and default gateway.

**Primary DNS Server:** Enter the IP address of primary DNS server that provides DNS service for TS-201 in external network.

**Secondary DNS Server:** Enter the IP address of secondary DNS server that provides DNS service for TS-201 in external network.

**Note:**
1. Please contact your ISP or network administrator for the IP address of primary and secondary DNS servers. When TS-201 plays the role as a terminal and needs to perform independent connection, e.g. BT download, you must enter at least one DNS server IP for proper URL connection. Otherwise, the function may not work properly.
2. If you select to obtain IP address via DHCP, there is no need to configure the primary and secondary DNS servers. You can enter "0.0.0.0" in the settings.

**Enable DHCP Server**

If no DHCP is available in the LAN where TS-201 locates, you can enable this function to enable TS-201 as a DHCP server and allocate dynamic IP address to DHCP clients in LAN.

You can set the range of IP addresses allocated by DHCP server and the lease time. Lease time refers to time that IP address is leased to the clients by DHCP server. When the time expires, the client has to acquire an IP address again.

For example, to establish a DLNA network, and share the multimedia files on TS-201 to DLNA DMP via UPnP while there is no NAT gateway that supports DHCP server, you can enable DHCP server of TS-201. TS-201 will allocate dynamic IP address to DMP or other clients automatically and set up a local network.

**Note:** If there is an existing DHCP server in your LAN, do not enable this function. Otherwise, there will be IP address allocation and network access errors.



**Jumbo Frame Settings (MTU)**

"Jumbo Frames" refer to Ethernet frames that are larger than 1500 bytes. It is designed to enhance Ethernet networking throughput and reduce the CPU utilization of large file transfers by enabling more efficient larger payloads per packet.

Maximum Transmission Unit (MTU) refers to the size (in bytes) of the largest packet that a given layer of a communications protocol can transmit.

TS-201 uses standard Ethernet frames: **1500 bytes** by default. If your network appliances support Jumbo Frame setting, select the appropriate MTU value for your network environment. TS-201 supports 4074 and 7418 bytes for MTU.

**Note:** Jumbo Frame setting is valid in Gigabit network environment only. Besides, all network appliances connected must enable Jumbo Frame and use the same MTU value.


Jumbo Frame Setting (MTU)
- Jumbo frame will only work in Gigabit network environment. Please make sure your clients are configured to use the same frame size.
- Jumbo frame setting will work only when all network appliances connected have enabled jumbo frame and use the same MTU value.
Select Jumbo Frame setting:
Disable Jumbo Frame, MTU value is 1500 bytes
Disable Jumbo Frame, MTU value is 1500 bytes
Enable Jumbo Frame, MTU value is 4074 bytes
Enable Jumbo Frame, MTU value is 7418 bytes

### 3.4.2 Microsoft Networking




**Enable file service for Microsoft networking:** If you are using Microsoft® Windows® OS, enable this service to access the files on network share folders. Assign a workgroup name.

✓ **Standalone Server**

Use local users for user authentication.

✓ **WINS server**

If the local network has a WINS server installed, specify the IP address. TS-201 will automatically register its name and IP address with WINS service. If you have a WINS server in your network and want to use this server, enter the WINS server IP.



- **Domain Master**

  There is a unique Domain Master Browser for collecting and recording resources and services available for each PC in the network or workgroup of Windows. When you find the waiting time for accessing Network Neighborhood too long, it may be caused by failure of an existing master browser, or there is no master browser in the network.

  If there is no master browser in your network, you can check the box Domain Master in this section to configure TS-201 as the master browser to enhance the speed of accessing information on Network Neighborhood.

### 3.4.3 Apple Network

To use TS-201 on Apple Mac operating system, enable AppleTalk network support. If your AppleTalk network uses extended networks, and is assigned with multiple zones, assign a zone name to TS-201. If you do not want to assign a network zone, enter an asterisk (*) to use the default setting. **This setting is disabled by default.**




### 3.4.4 Web File Manager

To access files on TS-201 via web browser, enable Web File Manager. If TS-201 is connected to the Internet and uses a valid IP address, you can access files on the server by web browser from anywhere. For more information, please refer to Chapter 9.

TS-201 supports SSL secure login. You can select SSL login on TS-201 administration page and login Web File Manager via https; or enter https://TS-201 IP:443/Qfilemanager/ in the browser.


Web File Manager
Enable Web File Manager
After enabling this service, click the following link to enter to Web File Manager.
http://10.8.12.27:6000/Qfilemanager/
Apply

### 3.4.5 FTP Service

When you enable FTP service, you can define the port number for the service and maximum number of users connected to the FTP at the same time.

Select to enable or disable Unicode Support. The default setting is No. Since most FTP clients do not support Unicode currently, it is recommended that you disable Unicode support here and select the language the same as your OS in "System Settings—Encoding Setting" page so that the folders and files on FTP can be properly shown (please refer to Chapter 3.3.3). If your FTP client supports Unicode, make sure you have enabled Unicode support for both your client and TS-201.


FTP Service
Enable FTP Service
Port Number
21
Maximum Connections
30
Unicode Support
Yes
No
Enable Anonymous
Yes
No
Note: If your FTP client does not support Unicode, please select "No" for Unicode Support and select a supported filename encoding from [Filename Encoding Setting] under [System Settings] so that the folders and files on FTP can be properly shown.
Apply

You can enable anonymous login to allow users to access the FTP server of TS-201 anonymously. The users can access the folders and files which are opened for public access. If this option is disabled, users must enter an authorized user name and password to access the server.


Log On As
To log on to this FTP server, type a user name and password.
FTP server: 10.8.12.7
User name: Anonymous
E-mail Address: IEUser@
After you log on, you can add this server to your Favorites and return to it easily.
The FTP server will use the e-mail address to identify anonymous users.
FTP does not encrypt or encode passwords or data before sending them to the server. To protect the security of your passwords and data, use Web Folders (WebDAV) instead.
Learn more about using Web Folders.
Log on anonymously
Log On
Cancel

### 3.4.6 Multimedia Station

To share multimedia files like photos, music or video files on the network, please enable Multimedia Station. For further information of Multimedia Station, iTunes service and UPnP Media Server, please refer to Chapter 5.


Multimedia Station
Enable Multimedia Station
After enabling this service, click the following link to enter Multimedia Station.
http://10.8.12.133/Qmultimedia/
Enable iTunes service
Label encoding
English
Please select the label encoding of the music files. Select the correct encoding to display the label information correctly. Please select English for non-Asian languages.
Enable UPnP MediaServer
After enabling this service, click the following link to enter UPnP MediaServer configuration page.
http://10.8.12.133:9000/
Apply

### 3.4.7 Download Station

TS-201 supports BT, HTTP and FTP download independent of PC/notebook. To use download function of TS-201, please enable Download Station. For further information, please refer to Chapter 6.


Download Station
Enable Download Station
After enabling this service, click the following link to enter to Download Station.
http://10.8.12.27:6000/Qdownload/
Apply

**Warning:** Please be warned against illegal downloading of copyrighted materials. The Download Station functionality is provided for downloading authorized files only. Downloading or distribution of unauthorized materials may result in severe civil and criminal penalty. Users are subject to the restrictions of the copyright laws and should accept all the consequences.

### 3.4.8 Web Server

You can publish your own server by enabling Web Server function of TS-201. Enter the port number for web server service, the default number is 80. For further information, please refer to Chapter 7.

Web Server
Enable Web Server ( PHP4, SQLite supported )
Port Number
80
After enabling this service, click the following link to enter to Web Server.
http://10.8.12.27:80/
Apply

### 3.4.9 DDNS Service


DDNS Service
After enabling DDNS Service, you can connect to this server by domain name.
(Note: If this server is placed behind a router, please use the DDNS service of the router.)
Enable Dynamic DNS Service
Select DDNS server:
members.dyndns.org
Enter the account information you registered with the DDNS provider:
User Name:
qnaptw
Password:
Host Name:
qnaptw.dyndns.org
Dynamic IP Address
Fixed IP Address
Apply

To set up a server on the Internet and enable users to access it easily, a fixed and easy-to-remember host name is often required. However, if ISP provides only dynamic IP address, the IP address of the server will change from time to time and is difficult to recall. You can enable DDNS service to solve the problem.

After enabling DDNS service of TS-201, whenever TS-201 restarts or the IP address is changed, TS-201 will notify DDNS provider immediately to record the new IP address. When the user tries to connect TS-201 via the host name, DDNS will transfer the recorded IP address to the user.

**Enable and configure DDNS of TS-201:**

Before using DDNS service, please register a host name from the DDNS provider*. TS-201 supports the 5 DDNS providers: members.dyndns.org, update.ods.org, members.dhs.org, www.dyns.cx, www.3322.org.

Enable Dynamic DNS Service, and select DDNS server. Then enter the user name, password, and hostname.

* For the information of DDNS service registration, please refer to the website of the DDNS providers.

**Note:** The DDNS function of TS-201 is not applicable when TS-201 is located behind an NAT router. Since the IP address sent from TS-201 to DDNS provider is virtual, which cannot be found on the Internet, the user will not be able to access TS-201. Therefore, when TS-201 is located behind an NAT, it is recommended to use an NAT router with DDNS function to perform DDNS function.

### 3.4.10 View Network Settings

You can view current network settings and status of TS-201 in this section.






## 3.5 Device Configuration

You can configure SATA disk, USB disk and USB printer settings in this section.



### 3.5.1 SATA Disk

This page shows the model, size and current status of the disk(s) installed on TS-201. You can format and check disks, and scan bad blocks on the disks. When the SATA disks are formatted, TS-201 will create the following default share folders:

- ✓ Public: Network share for file sharing
- ✓ Qdownload: Network share for Download Station
- ✓ Qmultimedia: Network share for Multimedia Station
- ✓ Qusb: Network share for data copy function via USB ports
- ✓ Qweb: Network share for Web Server



You can create the following disk volumes:

- **Single Disk Volume**
  Each disk will be used as a standalone disk. However, if a disk is damaged, all data will be lost.

- **RAID 1 Mirroring Disk Volume**
  RAID 1 (mirroring disk) protects your data by automatically backing up the contents of one drive onto the second drive of a mirrored pair. This protects your data if one of the drives fails. Unfortunately, the storing capacity is equal to a single drive, as the second drive is used to automatically back up the first. Mirroring Disk is suitable for personal or corporate use to store important data.

- **RAID 0 Striping Disk Volume**
  RAID 0 (striping disk) combines 2 or more drives into one larger disk. It offers the fastest disk access but it does not have any protection of your data if the striped array fails. The disk capacity equals the number of drives in the array times the size of the smallest drive. Striping disk is usually used to maximize your disk capacity or for fast disk access but not for storing important data.

- **Linear Disk Volume**
  You can combine two or more disks into one larger disk. During file saving, the file will be saved on physical disks sequentially but does not have a disk failure file protection function. The overall capacity of linear disk is the sum of all disks. Linear disk is generally used for storing large data and is not appropriate to use for file protection of sensitive data.

### 3.5.2 USB Disk

TS-201 supports USB disks and thumb drives for extended storage. Connect the USB device to the USB port of TS-201, when the device is successfully detected, the details will be shown on this page.



### 3.5.3 USB Printer

1. To provide printer sharing function for network users, you can simply connect a USB printer to the USB port of TS-201. TS-201 will detect the printer automatically.




2. A printer icon should be shown in the share folder of the server. Double click the icon.



3. Install the printer driver.




4. When finished, you can start to use network printer service of TS-201.

**Note:**
1. TS-201 supports general USB printer only but not multifunction printer.
2. TS-201 printer service is only supported in Windows OS but not Mac OS.
3. For the information of supported USB printer models, please visit http://www.qnap.com.

## 3.6 User Management

The files on TS-201 can be shared among multiple users. For easier management and better control of users' access right, you have to organize users, user groups and their access right control.




### 3.6.1 Users

The system has created the following users by default:

❶ **Administrator**

By default, administrator has access to system administration and cannot be deleted.

❷ **Guest**

This is a built-in user and will not be displayed on User Management page. When you use a non-registered user name to login, the server will recognize the user as a guest and will allow limited access. A guest does not belong to any user group. The login password for guest is **guest**.

❸ **Anonymous**

This is a built-in user and will not be displayed on User Management page. When you connect to the server by FTP service, you can use this name to login as a guest.

**512 users can be created at maximum** (including system default users). You can create a new user according to your needs. The following information is required to create a new user:

- ✓ **User name**
  The user name must not exceed 32 characters. It is case-insensitive and supports double-byte characters, such as Chinese, Japanese, and Korean except:
  **" / \ [ ] : ; | = , + * ? < > ` '**

- ✓ **Password**
  The password is case-sensitive and can be 16 characters long at maximum. It is recommended to use a password of at least 6 characters.

You can perform the following actions for user management:



### 3.6.2 User Groups

User group is a collection of users with the same access right to files or folders. TS-201 has created the following user groups by default:

❶ **Administrators**

All members in this group have administration right. You cannot delete this group.

❷ **Everyone**

All registered users belong to everyone group. You cannot delete this group.




You can manage user groups with the following options:

**1024 groups can be created at maximum.** A group name must not exceed 256 characters. It is case-insensitive and supports double-byte characters, such as Chinese, Japanese, and Korean, except the following ones:

**" / \ [ ] : ; | = , + * ? < > ` '**

**Create Users and Assign Users to User Group**

The following example demonstrates how to create new users and assign users to a user group.

ABC Co. has recently recruited two employees Mr. Jones Lee for Administration Department and Ms. Jane Wu for Sales Department. The IT Department therefore needs to create two user accounts for them to access company data on TS-201.

i. To create a user account, go to User Management-Users. Click **Create**.



ii. Enter the user name (Jones Lee/ Jane Wu) and password. Check the box "Continue to set the user groups to which this user belongs" and click **OK**.






iii. Select the user groups the users belong to on the right list, i.e. Mr. Jones Lee for Administration Dept and Ms. Jane Wu for Sales Dept, and click **Add**. Then click **Close**.






iv. The user names will appear on the list on Create User Page.



### Create Private Network Share for User Groups

You can create particular network share for each user group. The procedure is described as below:

1. To create a network share called **media** accessible by Administration Department only, please go to "User Management—User Groups" page. Select the user group Administration Dept and click **Create Private Network Share** on the right.




2. Enter the network share name **media**. Select the disk volume that the share will be created in and specify the path automatically or manually. Enter the comment for the network share, e.g. media folder for Admin Dept and click **Apply**.



3. You can see the folder **media** in **Network Share Management** page.




4. Enter Access Control. You can see that only Administration Dept has full access right to the folder.



### 3.6.3 Quota

To allocate disk volume efficiently, you can specify the quota that can be used by each user. When this function is enabled and a user has reached his/her disk quota, he/she cannot upload data to the server anymore. By default, no limitations are set for users. You can modify the following two options:

i. Enable quota for all users

ii. Quota size on each disk volume




Please refer to the following example to configure the quota setting of users: The IT department is planning to set the disk quota of Mr. Jones Lee from Administration Department and Ms. Jane Wu from Sales Department on TS-201. The disk quota is 2000MB for Mr. Jones Lee and 4000MB for Ms. Jane Wu.

1. Please go to **Quota** page in **User Management** to enable quota for all users. Enter the quota size on each disk volume, e.g. 1000MB. The quota for individual user can be modified later.



2. Select Jones Lee on User page and click **Quota Settings** on the right.




3. Enter the quota size 2000MB and click **OK**.




4. Follow the same steps and enter the quota size 4000MB for Jane Wu and click **OK**. The quota setting is successfully applied.



## 3.7 Network Share Management

The primary purpose of network storage is file sharing. You can create different network share folders for various types of files, and provide different file access rights to users or user groups.




There are five options in Network Share Management:

### 3.7.1 Create

To create a network share, enter the following information:

✓ Network share name

The length of the network share name cannot exceed 32 single-byte characters or 10 double-byte characters, and cannot contain the following characters:

**" . + = / \ : | * ? < > ; [ ] %**

✓ Disk volume

This area shows the disk volume status.

✓ Path

All data is stored under the assigned path onto the disk volume. You can select "Specify path automatically" or assign a path manually. The path cannot exceed 256 characters and cannot contain the characters below:

**" . + = / \ : | * ? < > ; [ ] %**

✓ Comment

Enter a brief description for the share folder. The comment cannot exceed 128 characters.



### 3.7.2 Property

To edit the property of an existing network share, select a share and click **Property**. You can then edit the content of that share.






### 3.7.3 Access Control

When a network share is created, you can assign access rights to users or user groups:

- ✓ Deny access
  Access to the network share will be denied.
- ✓ Read only
  Users can read the files only on the network share.
- ✓ Full access
  Users can read, write, create, or delete files and folders on the network share.




### 3.7.4 Delete

Select a share and click **Delete**. Click **OK** to confirm.


Please make sure you want to delete network share media.
Note: All active users who are currently using this network share will be disconnected.
OK
Cancel

### 3.7.5 Restore

If the default network shares of TS-201 are not created successfully, you can use the Restore function to restore the network shares. To do so, click **Restore** and the shares will be created.






## 3.8 System Tools

System Tools enable you to optimize the maintenance and management of TS-201.



### 3.8.1 Alert Notification

Enter the e-mail address of the administrator and the IP address of the SMTP server. In case of warning or malfunction, e.g. CPU fan fails, a drive fails or is unplugged, an email will be sent to the administrator automatically. You can go to Event Logs (refer to Chapter 3.9) to check the details of all errors and warnings.

If your mailbox requires SMTP authentication, enter the user name and password.

> **Note:** It is recommended to send a test e-mail to make sure you can receive the alert mails.




### 3.8.2 Restart/ Shutdown

Select to restart or shut down TS-201.

### 3.8.3 Hardware Settings

You can enable or disable the hardware functions of TS-201.

Hardware Settings
Enable configuration reset switch
Enable hard disk standby mode (if no access within 5 minutes Power LED will glow in blue and Status LED will be off)
Enable light signal alert when the free size of SATA disk is less than the value: 1 MB
Auto power on when power resumes after power loss
Apply

i. Enable configuration reset switch
   By enabling this option, you can press the reset button for 5 seconds to reset the administrator password and system settings to default.

ii. Enable hard disk standby mode
   When this function is enabled, hard disk will go to standby mode if there is no access within the specified period. The Power LED will glow in blue and the Status LED will be off in hard disk standby mode.

iii. Enable light signal alert when the free size of SATA disk is less than the value
   The Status LED will blink red and green when this function is enabled and the free space of the SATA disk is less than the value. The range of the value is 1-51200 MB.

iv. Auto power on when power resumes after power loss
   When this function is enabled, TS-201 will turn on automatically when power resumes after improper shutdown or power loss.

### 3.8.4 System Update


System Update
Note: If the system is running properly, you do not need to update the firmware.
Current firmware version: 2.0.0 Build 0105
Before updating system firmware, please make sure the product model and firmware version are correct. Follow the steps below to update firmware:
Step 1: Download the release notes of the same version as the firmware from QNAP website http://www.qnap.com/ Read the release notes carefully to make sure you need to update the firmware.
Step 2: Before updating system firmware, back up all disk data on the server to avoid any potential data loss during system update.
Step 3: Click the [Browse...] button to select the correct firmware image for system update. Click the [Update System] button to update the firmware.
Note: System update may take tens of seconds to several minutes to complete depending on the network connection status. Please wait patiently. The system will inform you when system update is completed.
Browse...
Update System

**Note:** If the system is running properly, you do not need to update the firmware.

Before updating system firmware, please make sure the product model and firmware version are correct. Follow the steps below to update firmware:

**Step 1:** Download the release notes of the same version as the firmware from QNAP website http://www.qnap.com. Read the release notes carefully to make sure you need to upgrade the firmware.

**Step 2:** Before upgrading system firmware, back up all disk data on the server to avoid any potential data loss during system update.

**Step 3:** Click the [Browse…] button to select the correct firmware image for system update. Click **Update System** to update the firmware.

**Note:** System update may take tens of seconds to several minutes to complete depending on the network connection status. Please wait patiently. The system will inform you when system update is completed.

### 3.8.5 Change Logo

You can choose your own picture to display on the login page of TS-201. The size of the picture cannot exceed 20K bytes.


Change Logo
Please select an image from the To be displayed pull-down menu. Then click [Apply] to confirm the change.
To upload your own image, click [Browse...] to select the image. Then click [Upload] to upload the image.
To replace an image, select an appropriate image from the To be replaced to pull-down menu and click [Apply].
Uploaded image:
Browse...
Upload
To be replaced to:
Not replace
Replace
To be displayed:
Image 1
Image 1
Image 2
Uploaded Image
Image 3
Image 4
Current Logo Image
Note: For the best image effect, the recommended size for the image is 100 x 100 pixels.
Apply

### 3.8.6 Remote Replication (Disaster Recovery)

Remote Replication enables you to replicate files on TS-201 to another TS-201 or QNAP NAS series. The files will be compressed before the replication process in order to save time for data transfer. **Make sure a network share is created before creating a remote replication task.**

**Using Remote Replication**

Login TS-201 and go to Remote Replication in System Tools.




**i. New**

a. Click **New** to enter the following page.



b. Complete all settings and click **OK** to save or **Cancel** to quit.




c. The port for remote replication is 873. If you are using two TS-201 servers behind an NAT router, please open the port 873 on NAT router and forward the port to the corresponding LAN IP of TS-201. Otherwise, the remote replication service will be blocked by NAT.

**Note:** To use remote replication, enable Microsoft Networking service, make sure the destination network share and directory have been created, and the user name and password are valid to login the destination folder.

**ii. Edit**

a. Select the task to be edited.

b. Click **Edit**.

c. Modify the settings.

d. Click **OK** to save or **Cancel** to quit.




**iii. Delete**

a. Select the task to be deleted.

b. Click **Delete**.



### 3.8.7 Backup / Restore / Reset Settings

- To backup all settings, including user accounts, server name and network configuration etc., click **Backup** and select to open or save the setting file.
- To restore all settings, click **Browse** to select a previously saved setting file and click **Restore** to confirm.
- To reset all settings to default, click **Reset**.


Backup/ Restore/ Reset Settings
To restore all settings, click Browse to select a previously saved setting file and click Restore to confirm.
To backup all settings, including user accounts, server name and network configuration etc., click Backup and select to open or save the setting file.
To reset all settings to default, click Reset.
Browse...
Restore
Backup
Reset

### 3.8.8 Network Recycle Bin

This function enables files deleted on the shares of TS-201 to be removed to Network Recycle Bin to reserve the files temporarily. To enable this function, check the box "Enable Network Recycle Bin" and click **Apply**. The system will create a network share "Network Recycle Bin" automatically.
To delete all the files in network recycle bin, click "Clean Network Recycle Bin".


Network Recycle Bin
Enable Network Recycle Bin
The system will create a network share "Network Recycle Bin" automatically after enabling network recycle bin. The files you deleted will be temporarily saved in the network recycle bin.
Click "Clean network recycle bin" to delete all the files in network recycle bin.
Clean Network Recycle Bin
Apply



## 3.9 Event Logs

TS-201 can store thousands of recent event logs, including warning, error and information messages. In case of system malfunction, event logs can be retrieved to analyze system problems.


Event Logs
Event Logs
Display All events
All events
Warnings and errors
Errors only
There are 53 events.
1
Type
Date
Time
Information 01/06/2006 18:01:36
Information System was shut down on Fri Jan 6 18:09:48 CST 2006. 01/06/2006 18:09:48
Information System was updated successfully from 1.0.0 to 1.0.0 01/06/2006 18:07:27
Information System was updated successfully from 1.0.0 to 1.0.0 01/06/2006 16:27:17
Information System started. 01/05/2006 11:07:22
Information System was shut down on Thu Jan 5 11:09:27 CST 2006. 01/05/2006 11:09:27
Error NIC Link is Down. 01/05/2006 11:09:25
Information Remote backup schedule qqq finished successfully. 01/04/2006 18:01:14
Information Remote backup schedule qqq starting. 01/04/2006 18:01:13
Information Remote backup schedule qqq finished successfully. 01/04/2006 18:00:42
Refresh
Clear

# Chapter 4. Copy Data Directly by Front USB Port to TS-201

TS-201 supports direct copy of data on USB devices to TS-201 by using the Copy button. To use this function, please follow the steps below:

1. Make sure a SATA disk is installed correctly in TS-201 according to the instructions in Chapter 2.1.
2. Turn on TS-201.
3. Format the SATA disk in SATA Disk page of Device Configuration (refer to Chapter 3.5.1). A system default folder **Qusb** will be created in TS-201.
4. Connect USB devices, e.g. digital camera, flash to the front USB port of TS-201.
5. Press the **Copy** button on TS-201. All data on the USB device will be copied to the folder **Qusb/(xxxxyyzz)*** on TS-201 instantly.

#Intelligent one touch copy button: TS-201 will detect the data in the connected USB device automatically. The first time a USB device is connected, press the Copy button and TS-201 will copy all data in the device automatically. When the same device is connected again and there are changes to the data in the device, press the Copy button and TS-201 will copy all files in the device. If there are no changes, press the Copy button and TS-201 will not copy the files.

* xxxx: year ; yy: month; zz: date

**Note:** USB auto copy function supports only USB device of 10GB storage capacity or less.

# Chapter 5. Multimedia Station

## 5.1 Share Photos and Multimedia Files via Web Interface

TS-201 provides a user-friendly web management interface for you to manage personal albums easily. You can view images and multimedia files, or browse photos by thumbnails preview.

### A. Upload photos by web administration

1. To use Multimedia Station of TS-201, make sure a SATA disk is installed correctly in TS-201 according to the instructions in Chapter 2.1. A share folder **Qmultimedia** will be created. Enable Multimedia function in **Network Settings**.


Network Settings
TCP/IP Configuration
Microsoft Networking
Apple Networking
Web File Manager
FTP Service
Multimedia Station
Download Station
Web Server
DDNS Service
View Network Settings
Multimedia Station
Enable Multimedia Station
After enabling this service, click the following link to enter Multimedia Station.
http://10.8.12.7:6000/Qmultimedia/
Enable iTunes service
Label encoding
English
Please select the label encoding of the music files. Select the correct encoding to display the label information correctly. Please select English for non-Asian languages.
Enable UPnP MediaServer
After enabling this service, click the following link to enter UPnP MediaServer configuration page.
http://10.8.12.7:9000/
Apply

2. Click on the link **http://TS-201 IP/Qmultimedia** on Multimedia Station page or click **Multimedia Station** on the login page of TS-201 to access Multimedia Station.


TS-201 Turbo Station
Administration
Change Password
SSL login
English
Web File Manager
Web Server
Multimedia Station
Download Station
A reliable and high capacity network attached storage server
• Share your storage over Microsoft and Apple network.
• Easy administration through simple web interface.
Welcome to TS-201
Thank you for using TS-201. TS-201 provides diversified applications and functions for you to enjoy pioneer technology.
(C) Copyright QNAP Systems, Inc. All rights reserved. Version 2.0.0 build 1207T

3. Click on the top right hand corner. Login with administrator name and password to manage Multimedia Station. Users without administration right can view the photos and multimedia files on Multimedia Station but they do not have the right to modify the files.



4. Click **Browse** to select the multimedia file and then click **Upload** to upload the file to the folder.




5. You can also create folders by clicking and upload files to the folders.

**B. Upload photos to Qmultimedia folder directly**

You can upload multimedia files to TS-201 directly by the following steps.

1. Use **Run** function in Windows. Enter \\[server name] or \\[server IP] to access share folder on TS-201.




2. Open the folder **Qmultimedia**. Enter the user name and password to login.




3. Drag the files and folders to the folder directly. Please wait patiently when TS-201 is generating thumbnails for images during uploading.

When you login Multimedia Station by web browser again, all multimedia files will be shown.




**Buttons on Multimedia Station page**

| | |
|---|---|
| A→Z | Sort files by name |
| | Sort files by size |
| 1 → 30 | Sort files by date |
| | Return to previous page |
| | Return to Home |
| | Create folder |
| | Rename file or folder |
| | Select all |
| | Select none |
| | Delete |

**Support file format list**

| Type | File format |
|---|---|
| Picture | jpg, bmp, gif |
| Video | wmx, wvx, avi, mpeg, mpg, mpe, m1v, mp2, mpv2, mp2v, mpa, dvr-ms, asf, asx, wpl, wm, wmx, wmd, wmz |
| Audio | wma, wax, cda, wav, mp3, m3u, mid, midi, rmi, aif, aifc, aiff, au, snd |
| Others | (Other formats not mentioned above) |

**View Photo Information**

1. To view detailed information of a photo, click on the thumbnail of the picture.




2. The information of the photo, e.g. file name, resolution, size, camera producer will be shown on the right. You can enter a description for the picture in the box below the photo and click **Submit**. To reset the description to previously saved version, click **Reset**.



**Buttons Description**

You can use the buttons on top of the photo to manage the album.

| | |
|---|---|
| | Back to previous level |
| | Previous image |
| | Next image |
| | Rotate image anticlockwise |
| | Rotate image clockwise |
| | Zoom in |
| | Zoom out |
|   | Play slideshow. Select the time interval in seconds. Click **play** to play slide show. To stop playing, click **stop**. |
| | Print the image |
| | Save the picture |

**Play music or video files**

To play music or video files on Multimedia Station, you can click on the thumbnail of the file displayed on the page. The file will be played by the default music or video playing program of your PC.

*It is recommended to use Media Player 10.0 or above as the default playing program.



## 5.2 Enable iTunes Service

Enable iTunes service on TS-201. The mp3 files on Qmultimedia folder of TS-201 will be shared via iTunes. All the computers with iTunes installed on LAN will be able to find, browse and play the music files on TS-201.


Multimedia Station
Enable Multimedia Station
After enabling this service, click the following link to enter Multimedia Station.
http://10.8.12.7:6000/Qmultimedia/
Enable iTunes service
Label encoding
English
Please select the label encoding of the music files. Select the correct encoding to display the label information correctly. Please select English for non-Asian languages.
Enable UPnP MediaServer
After enabling this service, click the following link to enter UPnP MediaServer configuration page.
http://10.8.12.7:9000/
Apply

**Note:** You can download the latest iTunes software from official Apple website http://www.apple.com.

## 5.3 Use UPnP Media Server

TS-201 is built-in with TwonkyMedia, DLNA compatible UPnP media server. Enable this function and TS-201 will share particular music, photos or video files to DLNA network. You can use DLNA compatible digital media player (DMP), to play the multimedia files on TS-201 on TV or acoustic sound system.




To use UPnP Media Server, please enable this function and click the following link (http://TS-201 IP:9000/) to enter the configuration page of UPnP Media Server.


Multimedia Station
Enable Multimedia Station
After enabling this service, click the following link to enter Multimedia Station.
http://10.8.12.7:6000/Qmultimedia/
Enable iTunes service
Label encoding
English
Please select the label encoding of the music files. Select the correct encoding to display the label information correctly. Please select English for non-Asian languages.
Enable UPnP MediaServer
After enabling this service, click the following link to enter UPnP MediaServer configuration page.
http://10.8.12.7:9000/
Apply

Click on the link http://TS-201 IP:9000/ to enter UPnP Media Server configuration page and configure the following settings.

(1) Language: Select the display language.

(2) Server Name: Enter the name of TS-201 UPnP Media Server. This name will be shown on DMP operation interface, e.g. NAS.

(3) Content Locations: Select the share folder on TS-201 to be shared to DMP. The default folder is Qmultimedia. You can add more than one share folder.

Click **Save Changes** to save the settings.


MediaServer
TwonkyMedia Configuration: Basic Setup
Version 4.2Q
Basic Setup
First steps
Internet Radio
Playlists
Advanced Setup
Content Locations
External applications
Naming
Advanced Setup
Content Locations
External applications
Naming
Content Locations
External applications
Naming
Music tree
Picture tree
Video tree
Network
Miscellaneous
Support
Troubleshooting
FAQ
Forum
© TwonkyVision GmbH (2003,2006). All rights reserved
Save Changes
Cancel
Terminate server
Restart server
Rescan content directories
Please note that some of the applied changes will only become effective after a server restarts!
Language:
English
Language in which configuration pages and the navigation tree on the client side will be presented.
Server name:
Name of the media server as displayed by client devices. By means of the macro %HOSTNAME% you can add the actual host name, e.g. TwonkyMedia [%HOSTNAME%].
Content Locations:
/Qmultimedia
All content types
Browse
All content types
Browse
Add new content directory
Directories where the server shall scan for content. Each directory can be limited to a certain media type. The default setting will scan for all content types.
Rescan in minutes:
120
This option specifies the rescan behavior of the server. If set to 0, automatic rescans are disabled. A positive value specifies the period between rescans of content directories in minutes. -1 enables the server to watch content directories automatically for new content without the need for rescans.

After configuring the settings, you can upload mp3, photos, or video files to Qmultimedia folder or other specified folders on TS-201.

**Note:** If you upload multimedia files to the default share folder but the files are not shown on Media Player, you can click "Rescan content directories" or "Restart server" on the Media Server configuration page.

The built-in UPnP Media Server of TS-201 is compatible with the DLNA DMP devices in the market.

**About UPnP and DLNA**

Universal Plug and Play (UPnP) is a set of computer network protocols promulgated by the UPnP Forum. The purpose of UPnP is to allow devices to connect seamlessly and to simplify the implementation of networks at home and in corporate environment. UPnP achieves this by defining and publishing UPnP device control protocols built upon open, Internet-based communication standards.

The term UPnP is gleaned from Plug-and-play, a technology for dynamically attaching devices to a computer directly.

The Digital Living Network Alliance (DLNA) is an alliance of a number of consumer electronics, mobile and personal computer manufacturers. Its aim is to establish a home network in which the electronic devices from all companies are compatible with each other under an open standard. The alliance also tries to promote the idea of digital home by establishing DLNA certification standard. All DLNA certified products connected to the home network can be accessed seamlessly to enable consumers to enjoy digital life conveniently.

# Chapter 6. Download Station

TS-201 supports BT, HTTP and FTP download mechanism. You can add download task to TS-201 and let the server finish downloading independent of PC.

**Warning:** Please be warned against illegal downloading of copyrighted materials. The Download Station functionality is provided for downloading authorized files only. Downloading or distribution of unauthorized materials may result in severe civil and criminal penalty. Users are subject to the restrictions of the copyright laws and should accept all the consequences.

1. To use Download Station, make sure one or two SATA disks are installed correctly in TS-201 according to the instructions in Chapter 2.1. A share folder **Qdownload** will be created. Enable this function in **Network Settings**.



2. Click on the link **http://TS-201 IP/Qdownload** on Download Station page or click **Download Station** on the login page of TS-201 to access Download Station.


TS-201 Turbo Station
Administration
Change Password
SSL login
English
Web File Manager
Web Server
Multimedia Station
Download Station
A reliable and high capacity network attached storage server
• Share your storage over Microsoft and Apple network.
• Easy administration through simple web interface.
Welcome to TS-201
Thank you for using TS-201. TS-201 provides diversified applications and functions for you to enjoy pioneer technology.
(C) Copyright QNAP Systems, Inc. All rights reserved. Version 2.0.0 build 1207T

3. Select Add new BT task or Add new FTP/HTTP task.

**(A) Add new BT task**

Click **Add new BT task** on the left and upload a torrent file. You can download legal torrent files by searching on the Internet. There are websites that provide legally sharing torrents e.g. www.legaltorrents.com. Please download the torrent files to your local disk and then upload them to TS-201.






**(B) Add new FTP / HTTP task**

To run an FTP download task, click **Add new FTP / HTTP task**. Enter the FTP URL of the download task and select the share folder to save the files. Enter the user name and password to login the FTP server (if necessary). Then click **OK** to start downloading.

To run an HTTP download task, click **Add new FTP / HTTP task**. Enter the HTTP URL of the download task and select the share folder to save the files. Then click **OK** to start downloading.




4. After uploading a download task, the task will appear on **View Run List**.



5. You can select an available download task and click **Set Share Time** to configure the time for sharing the torrent file, or click **Set Config** to set the maximum number of downloads at the same time (default value is 3). You can also set the maximum download and upload rate (default value is 0, which means unlimited), and port range (default range is 6881-6899).







**Note:** If the sharing time (larger than 0 hr) is set for a download task, the download task will be moved to Finish List after download completes and the sharing time ends.




6. To pause a running download task, select the task in **View Run list** and click **Pause/ Restart download task**. You can view tasks that are paused or finished in View Pause List and View Finish List respectively. To restart a paused task, select the task in **View Pause List** and click **Pause/ Restart download task**.




7. You can also increase or decrease task priority by clicking **Increase download priority** and **Decrease download priority** when there are multiple download tasks.



8. To delete a running, paused, or finished task, select the task and click **Delete download task**. You can select to remove the download task only and retain the downloaded files, or remove the task and downloaded files.







9. To logout Download Station, click on the top right hand corner.

10. To access the folders you have downloaded, please go to the share folder **Qdownload** of TS-201.



### Dump Diagnostic Information

To view the diagnostic details of a download task, select a task on the list and click [Dump Diagnostic Information].






The common reasons for slow BT download rate or download error are as follow:

1. The torrent file has expired, the peers have stopped sharing this file, or there is error in the file.
2. TS-201 has configured to use fixed IP but DNS server is not configured, or DNS server fails.
3. Set the maximum number of simultaneous downloads as 3-5 for the best download rate.
4. TS-201 is located behind NAT router. The port settings have led to slow BT download rate or no response. You may try the following means to solve the problem:
   a. Open the BitTorrent port range on NAT router manually. Forward these ports to the LAN IP of TS-201.
   b. The new TS-201 firmware supports UPnP NAT port forwarding. If your NAT router supports UPnP, enable this function on the NAT. Then enable UPnP NAT port forwarding of TS-201. The BT download rate should be enhanced.

# Chapter 7. Web Server

TS-201 enables you to upload web pages and manage your own website easily by Web Server function. It also supports PHP and SQLite for you to establish an interactive website. Once you activate Web Server function, you can access your own homepage from anywhere. You can add hyperlinks in your homepage to connect to all the features of TS-201, such as Download Station, Multimedia Station and Web Server.

1. To use Web Server, make sure a SATA disk is installed correctly in TS-201 according to the instructions in Chapter 2.1. A share folder **Qweb** will be created. Enable Web Server function and enter the port number in **Network Settings**.

2. You can upload your web pages to the folder Qweb by the following methods:
   a. By using samba: You can open a web browser and type **\\[TS-201 IP]\Qweb** or **\\[TS-201 name]\Qweb**. Login the folder and upload your web pages.
   b. By FTP: You can login FTP service and upload your web pages to the folder (please refer to Chapter 8).
   c. By Web File Manager: You can login Web File Manager and upload your web pages to the folder (please refer to Chapter 9).

The file index.html, index.htm or index.php will be the home path of your webpage.



3. Click on the link **http://TS-201 IP/** on Web Server page or click **Web Server** on the login page of TS-201 to access the web page you upload. Note that when Web Server is enabled, you have to type [http://TS-201 IP address:6000] in your web browser to access the login page of TS-201.

Web Server
Enable Web Server ( PHP4, SQLite supported )
Port Number
80
After enabling this service, click the following link to enter to Web Server.
http://10.8.12.27:80/
Apply


TS-201 Turbo Station
Administration
Change Password
SSL login
English
Web File Manager
Web Server
Multimedia Station
Download Station
A reliable and high capacity network attached storage server
• Share your storage over Microsoft and Apple network.
• Easy administration through simple web interface.
Welcome to TS-201
Thank you for using TS-201. TS-201 provides diversified applications and functions for you to enjoy pioneer technology.
(C) Copyright QNAP Systems, Inc. All rights reserved. Version 2.0.0 build 1207T

**SQLite Management**

SQLiteManager is a multilingual web-based tool to manage SQLite databases and can be downloaded from http://www.sqlitemanager.org/.

Please follow the steps below or refer to the INSTALL file in the downloaded SQLiteManager-*.tar.gz[?] to install the SQLiteManager.

(1) Unpack your download file SQLiteManager-*.tar.gz.

(2) Upload the unpacked folder **SQLiteManager-*** to **\\TS-201 IP\Qweb**.

(3) Open your web browser and go to **http://TS-201 IP/SQLiteManager-*/**.

[?]: The symbol "*" refers to the version number of SQLiteManager.

# Chapter 8. FTP Server

TS-201 supports FTP service. To use FTP service, enable this function in **Network Settings** and follow the steps below:




1. Open an IE browser and enter **ftp://[TS-201 IP]** or **ftp://[TS-201 name]**. OR

2. By Web File Manager of TS-201.
   a. Go to TS-201 administration page and click **Web File Manager**. Enter user name and password to login TS-201.


TS-201 Turbo Station
Administration
Change Password
SSL login
English
Web File Manager
Web Server
Multimedia Station
Download Station
A reliable and high capacity network attached storage server
• Share your storage over Microsoft and Apple network.
• Easy administration through simple web interface.
Welcome to TS-201
Thank you for using TS-201. TS-201 provides diversified applications and functions for you to enjoy pioneer technology.
(C) Copyright QNAP Systems, Inc. All rights reserved. Version 2.0.0 build 1207T

b. Click **FTP**.

c. Enter the user name and password to login FTP service.


Log On As
Could not login to the FTP server with the user name and password specified.
FTP server: 10.8.12.19
User name: administrator
Password:
After you log on, you can add this server to your Favorites and return to it easily.
FTP does not encrypt or encode passwords or data before sending them to the server. To protect the security of your passwords and data, use Web Folders (WebDAV) instead.
Learn more about using Web Folders.
Log on anonymously
Save password
Log On
Cancel

d. You can start to use FTP service.



# Chapter 9. Web File Manager

## Using Web File Manager

To use Web File Manager, enable web service in Network Settings first.



Launch the web browser and go to TS-201 administration page. Select **Web File Manager** and enter the correct login name and password. You can login as "guest" to access the network shares open to guest access on TS-201. The login password of guest is **guest**.

| | |
|---|---|
| | **Note:** Make sure a network share has been created before using Web File Manager. |


TS-201 Turbo Station
Administration
Change Password
SSL login
English
Web File Manager
Web Server
Multimedia Station
Download Station
A reliable and high capacity network attached storage server
• Share your storage over Microsoft and Apple network.
• Easy administration through simple web interface.
Welcome to TS-201
Thank you for using TS-201. TS-201 provides diversified applications and functions for you to enjoy pioneer technology.
(C) Copyright QNAP Systems, Inc. All rights reserved. Version 2.0.0 build 1207T

Select an existing network share.

You can organize share folders of TS-201. With Web File Manager, you can upload, rename, or delete files and folders in the network shares.




### View files online

Click on a file displayed on the web page. The information of the file will be shown. If your browser does not support the file format, a download window will pop up automatically. Download the file and you can open it on your PC.

### Create folder

i. Select a network share or folder in which you want to create a new folder.

ii. Click (Create Folder) on the toolbar.

iii. Enter the name of the new folder and click OK.

### Rename file or folder

i. Select a file or folder to rename.

ii. Click (Rename) on the toolbar.

iii. Enter the new file or folder name and click OK.

### Delete file or folder

i. Select a file or folder to delete.

ii. Click (Delete) on the toolbar.

iii. Confirm to delete the file or folder.

To delete all files and folders, click (Select All) and (Delete).

### Upload file

i. Open the folder to upload file to.

ii. Click **Browse** to select the file.

iii. Click **Upload**.

### Download file

i. Select a file to download.

ii. Right click the file and select "Save Target As" to save the file.

### Logout

To exit Web File Manager, click (Logout).

## View Files Named in Local Language

To view files named in Chinese, you may have to configure the browser settings. Take Internet Explorer as an example, follow the steps below to configure the settings.

1. Click on **Tools** in IE browser.







5. Restart the browser.

**Web File Manager Icons**

| Icon | Description |
|---|---|
| | Return to the parent folder |
| | Refresh the current page |
| | Return to network share list home page |
| | Create folder |
| | Rename file or folder |
| | Delete file or folder |
| | Select all |
| | Cancel selection |
| | Logout |
| | Full access network share folder |
| | Read-only network share folder |
|  | Malfunction network share folder |

# Chapter 10. NetBak Replicator

NetBak Replicator is a powerful program installed in user's system (Windows® OS only) for data backup. You can back up any files or folders on local PC to specified share folder on TS-201 by LAN or WAN.

**Main Functions**

**1. Backup**

- Instant Backup
  You can select files and folders on local PC and back up files to specified network share folder on TS-201 immediately.

- File Filter
  You can select particular file types to be excluded from backup. The system will filter all files belonging to these file types when backing up data.

- Schedule
  You can specify a schedule for backing up data with this option, e.g. 12:00 every day or 05:00 every Saturday.

- Monitor
  When this option is enabled, the system will upload all files or folders to the server instantly for backup when the files or folders are modified.

**2. Restore**

Select this option to restore backed up data to the original location of the file or to a new directory.

**3. Log**

Enable this option to record events of NetBak Replicator, e.g. the time when NetBak Replicator starts and terminates.

**Install NetBak Replicator**

1. Select **Install NetBak Replicator** in TS-201 CD-ROM.




2. Follow the steps to install NetBak Replicator.

3. Upon successful installation, a shortcut icon

will be shown on the Desktop. Double click the icon to run NetBak Replicator.

**Use NetBak Replicator**

1. Before using NetBak Replicator, please login TS-201 administration and go to **Network Share Management** to create a share folder for backup. Make sure the share folder is open for everyone access or you login the share folder with an authorized account or administrator by NetBak Replicator.



2. Run NetBak Replicator. Click . All TS-201 and their share folders within the network will be displayed.



3. When the following window appears, all TS-201 in the LAN will appear on the left list. Select a server and a share folder on the right. NetBak Replicator also supports backup via WAN, you can enter the IP address of TS-201 for data backup directly and select a share folder. Then click **OK**.




4. Enter the user name and password to login the server.




5. You can start the backup procedure upon successful connection to the TS-201.

**Description of Buttons on NetBak Replicator**

| | |
|---|---|
| | Open Configuration: Open a previously saved NetBak Replicator configuration. |
| | Save Configuration: Save the settings on NetBak Replicator. The file will be named as *.rpr |
| | Select All: Select all items in the window. |
| | Clear All: Clear selection. |
| | Select My Document: Select all folders in My Document. |

- **Backup**

  Select files and folders for backup.

✓ Start

When you have selected the files for backup to TS-201, click **Start** on NetBak Replicator. The program will start to copy the selected files to the specified share folder on TS-201.



✓ File Filter

Click **File Filter** on NetBak Replicator main page to select file format to be skipped from backup. Then click **OK**.



✓ Schedule

Click **Schedule** on NetBak Replicator main page. Then check the box "Enable Backup Schedule" and select the frequency and time for backup. Click **OK** to confirm.



✓ Monitor

Select a folder for monitoring. When this option is enabled, the system will upload all files or folders to the server instantly for backup when the files or folders are modified. Other files will be gray and cannot be selected. Click **Monitor** again to cancel monitoring. An icon will appear on task bar of Windows® when monitoring is in process.



✓ Initialize Configuration

When using this function, NetBak Replicator will record all current settings of the user, including whether or not monitor function is enabled. When the user login again, this program will load the previous recorded settings for users to manage data backup.

- **Restore**

  Please follow the steps below to restore files from TS-201 to your PC.

  a. Restore to original position: Select the location that the data will be restored to.

  b. Select new restore position: Click to select the directory to restore data to or select a previously chosen location from the drop-down menu.

  c. Select the folder(s) and sub-folder(s) for restoring data on the right list and click **Start**.



d. Option: Select recovery option and error option.

If the restoring file existed, NetBak Replicator will:

- ✓ Overwrite all the files
- ✓ Ask first
- ✓ Skip this file

If an error happens in the process of file restoring, NetBak Replicator will:

- ✓ Stop the restoring
- ✓ Ask first
- ✓ Ignore this error message

- **Log**
  a. Save As…: To save all logs on NetBak Replicator, click this button. All logs will be saved as text file.
  b. Clear All: Click this button to clear all logs.
  c. Option: Select the type of logs to be recorded— "Record all logs" or "Record error logs only".

# Chapter 11. TS-201 Maintenance

This section provides a general overview on system maintenance.

## 11.1 Restart/ Shut down Server

Follow the steps below to restart or shut down TS-201.

1. Enter the administration page and select Restart/ Shutdown in System Tools.
2. Click **Restart** to reboot the server or **Shut Down** to turn off the server.

## 11.2 Reset Administrator Password and Network Settings

To reset the administrator password and network settings of TS-201,

1. Press the reset button of TS-201 for a few seconds. A beep sound will be heard.
2. Login TS-201 with the default user name and password:

| |
|---|
| Default user name: **administrator**<br>Password: **admin** |

| | |
|---|---|
| | **Note:** To reset the system by the reset button, the option "Enable configuration reset switch" in Hardware Settings must be activated. |


System Tools
Alert Notification
Restart/ Shutdown
Hardware Settings
System Update
Change Logo
Remote Replication
Backup/ Restore/ Reset Settings
Network Recycle Bin
Hardware Settings
Enable configuration reset switch
Enable hard disk standby mode (if no access within 5 minutes Power LED will glow in blue and Status LED will be off)
Enable light signal alert when the free size of SATA disk is less than the value: 1 MB
Auto power on when power resumes after power loss
Apply

## 11.3 Disk Failure or Malfunction

When you encounter disk malfunction or failure, please do the following:

1. Record the malfunction status or error messages shown in Event Logs.
2. Stop using the failed TS-201 and turn off the server.
3. Contact customer service for technical support.

| | |
|---|---|
| | **Note:** TS-201 must be repaired by professional technicians, do not try to repair the server yourself.<br>Please back up any important files or folders to avoid potential data loss due to disk crash. |

## 11.4 Power Outage or Abnormal Shutdown

In case of power outage or improper shutdown of TS-201, the system will resume to the state before it is shut down. If your server does not function properly after restart, please do the following:

1. If the system configuration is lost, configure the system again.
2. In the event of abnormal operation of the server, contact customer service for technical support.

To avoid the above situations, please back up your data periodically and make sure you have done the following:

- Follow the instructions described in Chapter 11.1 to restart or shut down the server.
- If there is an anticipated power outage, back up all important data and turn off the server properly until power supply is resumed.

# Technical Support

QNAP provides dedicated online support and customer service via instant messenger.  You can contact us by the following means:

Online Support: http://www.qnap.com
E-mail: support@qnap.com.tw
MSN: support@qnap.com.tw
SKYPE: qnapskype

# GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

**Preamble**

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the

software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.
Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.
The precise terms and conditions for copying, distribution and modification follow.

**TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION**

**0.** This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".
Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

**1.** You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.
You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

**2.** You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications

or work under the terms of Section 1 above, provided that you also meet all of these conditions:

**a)** You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

**b)** You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

**c)** If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, does not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

**3.** You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

**a)** Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
**b)** Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
**c)** Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in objects code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

**4.** You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

**5.** You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept

this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

**6.** Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

**7.** If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

**8.** If the distribution and/or use of the Program are restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

**9.** The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.
Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

**10.** If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

**NO WARRANTY**

**11.** BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR

CORRECTION.

**12.** IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

**END OF TERMS AND CONDITIONS**